

ACTIVESHOP[®]

USER MANUAL

Pro Wax Wax Melter, 400 ml Can with Thermostat, 120W
(model AX400)



Importer:
ACTIVESHOP SP. Z O.O.
8b Graniczna St., Bldg. DC2A
54-610 Wrocław, Poland
www.activeshop.com.pl
Rev. A/07/2026



Scan for
different
languages



Thank you for choosing our product.

Before using the product, please read the entire manual carefully and keep it for future reference.

This professional digital wax heater is suitable for all types of hair removal waxes. Easy to use. Melts all types of hair removal wax: wax in a can, hard wax, and wax pellets (the heater comes with a small pot in which you can melt hard wax and wax pellets).

Technical Specifications	
Power	120W
Capacity	400 ml
Power supply input voltage	220–240 V ~ 50/60 Hz
Temperature range	25–135°C

Instructions for use

1. Place the wax in the container, close the lid, and plug the device into an outlet.
2. Turn the knob clockwise to turn it on and set the desired temperature.
 - The temperature will be shown on the display.
 - The average time it takes for the wax to melt is about 15 minutes, depending on the type of product.
3. Once the wax has melted, lower the temperature on the device.
4. Before applying the wax, test the temperature on a small area of skin to avoid burns
5. Apply the wax to the skin with a stick in the direction of hair growth.
6. Apply the strip, press it down firmly with your hand, and then pull it off quickly against the direction of hair growth.
7. Remove any wax residue with oil or olive oil.
8. After finishing the treatment, turn off the device and unplug it.
9. Do not expose the waxed skin to the sun or UV rays for 24 hours after the treatment.

Cleaning and Maintenance

- Be sure to unplug the device from the power source before cleaning.
- It is best to clean the housing with a cloth dampened with a special liquid designed to remove wax residue.
- Do not clean the device directly under running water.
- Do not use sharp objects, abrasive cleaners, highly corrosive pastes, or solvents to clean the wax collector.

Recommendations

1. Make sure you install the device on a flat, stable surface to reduce the risk of it falling and being damaged.
2. Never leave the device plugged in and unattended.
3. Use the device as intended, as described in the manual.
4. Never use this device if the cord or plug is damaged.
5. Do not use the device if it is not working properly or if it has been dropped, damaged, or submerged in water.
6. Do not pull directly on the cord to unplug the device from the outlet.
7. This product is for indoor use only. Do not expose it to direct weather conditions.

8. Clean the device periodically to prevent dirt buildup. It is best to clean the device with a damp cloth.
9. Do not wrap the power cord around the device.

Safety Precautions

1. This device is professional equipment intended for use in beauty salons. To avoid adverse effects during treatment, the device must be operated exclusively by qualified beauty professionals.
2. Do not disassemble the device or attempt to use it for purposes other than those specified in this user manual. All maintenance and repairs must be performed exclusively by an authorized service technician (ACTIVESHOP Sp. z o.o.).
3. Do not install or operate the device near liquids, in wet areas, or with wet hands. Ensure that no liquids enter the device.
4. Immediately unplug the device from the outlet and contact the authorized service center provided by ACTIVESHOP Sp. z o.o. in the following cases: a) liquid has entered the device, b) the device emits a strange odor, smoke, or makes unusual noises, c) the power cord has been damaged, d) the device has been knocked over or its housing has been damaged.
5. Do not place any objects on the cables. Do not install the device in locations where someone might step on the power cord.
6. For safety reasons, unplug the power cord from the outlet after each use of the device.
7. Do not place any foreign objects inside the device. If a foreign object gets inside, unplug the power cord from the outlet and contact the distributor or manufacturer.
8. Do not place the device on an unstable cart, shelf, or vehicle. If it falls, the device may be damaged.
9. To ensure the device's specified service life, it is recommended to wait one minute before pressing the power button again (between turning it on and off and vice versa).
10. The power supply must comply with the specifications listed on the nameplate. Otherwise, there is a risk of the device malfunctioning, being damaged, or even catching fire.

CAUTION

1. In the event of damage to the power cord or other malfunctions, contact an authorized service center—this will help prevent hazards.
2. This device may be used by children aged 8 and older, by persons with reduced physical or mental capabilities, as well as by persons unfamiliar with the operation of this equipment, provided they are given appropriate supervision or instruction on how to use it safely and understand the associated risks.
3. Do not leave the device unattended when children or people who do not have sufficient knowledge of how to use the device are nearby.
4. This device is not intended for use by children. Do not allow children to play with the device.
5. This electrical device is not a toy. Improper use of or contact with the may pose a risk of injury or death; therefore, the device must be used and stored out of the reach of children.

Disposal of the device



To protect the environment, in accordance with Directive 2012/19/EC on waste electrical and electronic equipment, used electrical devices must be collected separately and taken to collection points for waste electrical and electronic equipment. Follow the guidelines for disposing of this type of equipment and do not dispose of it in household waste bins.

At the end of their useful life, these devices still contain valuable components suitable for recycling; therefore, they should be sent for recycling to appropriate collection points or to ACTIVESHOP Sp. z o.o.

Storage and Transport

The device should be transported at temperatures ranging from (-20°C) to $(+40^{\circ}\text{C})$ exclusively in its original packaging. Store it in a well-ventilated room with a relative humidity of no more than 90%. Operating temperature range: from $(+10^{\circ}\text{C})$ to $(+40^{\circ}\text{C})$. During storage and transport, the device must not be thrown or dropped, nor exposed to mechanical shocks or the elements.