ACTIVESHOP®

INSTRUCTIONS FOR USE

Pedicure spa chair with massager 308



Importer:
ACTIVESHOP Sp. z o.o.
Ul. Graniczna 8b, building
DC2A 54-610 Wroclaw,
Poland
www.activeshop.com.pl
Rev. A/06/2024

The cosmetic chair is equipped with a foot massager (in the form of a bowl), making it ideal for pedicure treatments. When turned on, the massager vibrates generating bubbles. In addition, the massager bowl has an opening where you can install various tips to enhance the effect of the treatment.

Attention!

Children and inexperienced people should not use this device. Children must be supervised and should not play near the chair.

Before using the cosmetic chair, read the instructions and perform the following steps:

1. Make sure all packaging materials have been removed.
2. Make sure the chair is in working order.
3. Place the chair in the area where it will be used.

Dimensions of the device:



Maximum load of the chair: 130kg.

Device functions:

1. Adjusting the footrest

The chair is equipped with a footrest that can be easily adjusted using the knob on the bottom. To lower or raise the footrest, unscrew the knob and set the footrest to the desired height, then tighten the knob. In addition, the footrest can be tilted to the right or left side for complete comfort during treatment.



Adjustment knob

2. Adjusting the height of the chair

The height of the seat can be adjusted using the actuator located under the seat. Pull the actuator and lower or raise the seat to the desired position. The seat height is adjustable from 44-55cm.
In addition, the seat of the chair rotates 360^{o}.

3. Massager functions

The device has a foot massager in the form of a bowl, which can be easily removed and installed. The massager is adjustable with a dial and has several modes. To select any of them, turn the dial to the appropriate mode.

Caution!

Do not turn on the massager if there is no water in it.



Control knob

Massage modes:

- vibratory

- bubble with water heating

- vibration-bubble with infrared and water heating The dial set to 0

means that the massager is off.

Operating instructions:

1. Place the chair in the treatment area.
2. Fill the bowl with water, not exceeding the maximum liquid level.
3. Then connect the device to the power supply.

4. Select the appropriate operating mode by turning the dial.
5. When the treatment is finished, turn the knob back to the 0 position and disconnect it from the power supply.
6. Then pour the water out of the bowl. Do not leave the water in the bowl for a long time to avoid damaging the device.

Cleaning and disinfecting the device:

- Do not use products with kerosene, alcohol, ammonia or other corrosive agents for cleaning.
- Unplug the device before cleaning.
- To keep the chair surface in good condition, clean it regularly. Remember to clean and disinfect the chair after each use. It is recommended to perform a thorough disinfection once a month.

I Metal and plastic surfaces

- To clean metal and plastic surfaces wipe them with a damp cloth. To clean hard-to-reach areas or corners, a small brush will work well. Do not use too much liquid to clean the device. Then disinfect the device with a suitable liquid.

II Stainless steel surfaces

- Cleaning with a mild detergent solution will work best. Avoid chlorine-based solutions.

III Painted or chrome-plated metal surfaces

- Do not use water jets (showers, high-pressure water cannons) for cleaning.
- Do not clean in high temperature and high humidity, and do not expose the device to conditions that may lead to liquid contamination.
- Do not use solvents and acids for cleaning.

IV Chair surface

- Wipe the seat surface evenly with a special leather cleaner, then wipe it with a clean, soft cloth.

Maintenance

Unplug the device before maintenance.

- Repairs should be performed by experienced and manufacturer-authorized personnel.
-Repairs by unauthorized personnel may cause injury injury or damage to the equipment for which the manufacturer is not responsible.
- Use only original spare parts approved by the manufacturer.
- Do not use the cosmetic chair or accessories if they are not working properly.
- All maintenance and repair work must be documented.

Maintenance measures

- Check controls and their wiring once a week. Check the condition and function, of the following items at least once every six months:
- Power cord and its attachment
- Motor wiring
- The control box and its wiring
- Are the accessories fixed
- Normal operation of the locking system

If you find any defects, stop using the equipment and contact an authorized service center. Only experienced or authorized personnel can open or replace the actuator / control unit.
If any part of the equipment is damaged, unplug the power cord and stop using it. Then notify the service center.

SAFETY MEASURES

1. The device is a professional equipment for use in beauty parlors. Operation of the device only by qualified cosmetic personnel avoids undesirable consequences during treatment.

2. Do not disassemble the device or attempt to use it for purposes other than those indicated in this manual. All servicing and repairs must be performed only by an authorized service technician (ACTIVESHOP L t d . company).

3. Do not install or operate the device near liquids, wet places or with wet hands - so that no liquids get into the device.

4. Immediately unplug the device from the outlet and contact the authorized service provided by ACTIVESHOP Ltd. in the following cases:

a) liquid has entered the device, b) the device emits a strange odor, smoke or makes strange sounds,

c) the power cord has been damaged, d) the device has been knocked over or its housing has been damaged.

5. Do not lay any objects on the cables. Do not install the device where someone may step on the power cord.

6. For safety purposes, unplug the power cord from the outlet every time you finish working with the device.

7. Do not insert anything into the opening of the device. If a foreign object gets into the hole, remove the cord from the outlet and contact the distributor or manufacturer.

8. Do not place the device on an unstable cart, shelf or vehicle. If dropped, the device may be damaged.

9. In order to guarantee the established useful life of the device, it is recommended to maintain an interval of one minute before pressing the power button again (between switching on and off and vice versa).

10. The power supply must comply with the specifications on the nameplate. Otherwise, there is a risk of incorrect operation of the device its damage and even burning.

CAUTION:

1. In case of damage to the power cord or other malfunctions, contact an authorized service center - this will avoid danger.

2. This device can be used by children at least 8 years old and by people with reduced physical and mental capabilities and those with inexperience and lack of familiarity with the equipment, if supervision or instruction on how to use the equipment in a safe manner is provided, so that the associated risks are understood.

3. The equipment is not intended for play by children. Do not allow children to play with the equipment.

4. Do not leave the appliance unsupervised when children or persons without sufficient knowledge in the use of the appliance are near it.

5. This electrical appliance is not a toy. Improper use or contact with the electrical appliance may pose a health risk or lead to death, so use and store the appliance out of the reach of children.



DISPOSAL OF THE DEVICE

Dispose of used electrical appliances, fixtures and packaging to raw material reprocessing centers in accordance with environmental protection principles. Do not dispose of electrical appliances in household waste containers. Follow the rules for the disposal of this type of equipment

equipment. In order to protect the environment in accordance with Directive 2012/19/EC on waste electrical and electronic equipment, waste electrical equipment should be collected separately and then handed over to the points of

collection of waste electronic and electrical equipment. At the end of their useful life, as well as old appliances contain full-value recyclable components, so they should be handed over for reprocessing. Therefore, they should be handed over to appropriate collection points, as well as they can also be handed over to ACTIVESHOP Ltd.

STORAGE AND TRANSPORT

The device should be transported at temperatures between (-) 20 °C and (+) 50 °C only in its original packaging. Store the device in a well-ventilated area with a relative humidity of no more than 75%. Operating temperature from (+) 10 °C to (+) 40 °C. During storage and transportation processes, the device must not be thrown or dropped, exposed to mechanical shocks or atmospheric agents.