ACTIVESHOP®

INSTRUCTIONS
USE INSTRUCTIONS

Giovanni D-008 vapozone



Importer:
ACTIVESHOP Sp. z o.o.
8b Graniczna St., building
DC2A 54-610 Wroclaw,
Poland
www.activeshop.com.pl
Rev. A/10/2024

Technical data:

Rated voltage	**220V/240V**
Electrical power	**800W**
Rated frequency	**50/60Hz**
Capacity	**600ML**
Steam temperature	**Approximately 40ºC (20cm from the nozzle)**

Notes before use:

- Do not use the device near a bathtub, sink or other wet vessel.
- It is not allowed to use the dish by people who are incapable of feeling heat. It may cause burns to the body.
- Stop using the device immediately if you experience any pain or abnormality on your skin or body.
- The following people should not use the product:
    - Women who are pregnant or menstruating, it may cause skin problems due to hormonal imbalance.
    - People with allergies, skin diseases, atopic dermatitis, sensitive skin or have suffered a severe sunburn.
    - People with skin injuries, eczema, swelling, etc.
    - Persons who have recently undergone surgery.
- When connecting the plug, do not touch the metal parts of the plug.
- Turn off the power and unplug the plug from the socket when you are not using the device. Failure to do so may cause a fire.
- Clean the device periodically to prevent dust accumulation. Moisture and other factors may cause the insulation to break through.
- Do not wrap the power cord around the device, it may cause the malfunction of the cable.
- Always make sure that the device is powered from a source with the correct voltage rating. Make sure the plug is properly inserted into the outlet. Failure to do so may result in fire, electric shock or burns
- Do not plug or unplug the device from the outlet with wet or damp hands.
- Do not use the device under the following conditions:
    - When the cord or plug is hot or damaged;
    - When the plug is loose in the outlet;
- Do not modify, stretch, excessively bend or twist the cord.
- Do not place anything heavy on the cord.
- Prevent dust or other harmful elements from getting into the plug.
- Do not use or store the device in the bathroom or other areas with high humidity. This may lead to electric shock, fire or insulation damage.
- Do not allow children to use the device.
- Do not use the device near flammable substances such as alcohols, solvents, gasoline, spray aerosols, etc. This may lead to explosion or fire.
- Do not immerse the device in water. Use the reservoir to replenish the water necessary for the operation of the device.
- Do not hit or throw the device. If the device is damaged by hitting or falling, you cannot continue using it.
- Do not insert anything into the nozzle or pinch the nozzle, as this may result in electrical shock.
- Do not attempt to disassemble or repair the equipment. For repair purposes, contact either the distributor from whom the equipment was purchased or an authorized service center

Features:

1. The device will automatically turn off when the water level in the tank is insufficient.

2. The device produces warm steam.
3. The device has an "ozone" function.

Notes on use on the skin

1. Excessive use is harmful to the skin.
2. Initially, the device should be used only once a day, no longer than 10 minutes.
3. Use 2-3 times a week for normal skin and once a week for sensitive skin.
4. If discomfort is felt on the skin during use, stop the treatment immediately.
5. Steam opens clogged pores, allowing deep cleansing of the skin.
6. Steam alleviates signs of aging and cleanses the skin of toxins.
7. The treatment also improves blood circulation.
8. After the treatment, it is recommended to moisturize the skin.
9. The device should be cleaned periodically.

Preparation

1. When you open the package for the first time, you may see residual water in the container. This is water left over after quality control at the factory and will not cause any hygienic problems.
2. Place the device on a flat, stable surface.
3. Unscrew the water container. Fill the water container (**with filtered or distilled water**) and screw the cap on.
4. Connect the device to a proper power source.
5. Turn on the device. The device will beep if there is no, contaminated or insufficient amount of water.
6. Want to turn on the hot steam treatment, press the "POWER" button, which will be highlighted in red. Fill the water to the maximum state. The heater will begin to heat the water, and the warm mist will start to come out after some time.
7. By pressing the "OZONE" button, the amount of steam will increase significantly.
8. The head of the vaporizer can be rotated.
9. After signaling an error, the device should be restarted.

Care Instructions

1. Keep the nozzle at least 20cm away from the face to cover the entire face with steam. Direct the steam jet to the top of your chin.
2. The steam will start to come out after a few tens of seconds of starting the device.
3. When the amount of water is insufficient, the steam jet will decrease accordingly. When there is not enough water, the machine will automatically turn off. Do not take out the water container right after the appliance is turned off. The water container needs at least 10 minutes to cool down, otherwise it may cause burns.
4. If the unit automatically shuts down due to a shortage of water, wait about 2 minutes until the controller restarts and the unit can return to operation.
5. Do not leave water in the tank. When finished, empty and dry the tank.



SAFETY PRECAUTIONS

1. The device is a professional equipment for use in beauty parlors. Operation of the device only by qualified cosmetic personnel avoids undesirable consequences during treatment.

2. Do not disassemble the device or attempt to use it for purposes other than those indicated in this manual. All servicing and repairs must be performed only by an authorized service technician (ACTIVESHOP L t d . company).
3. Do not install or operate the device near liquids, wet places or with wet hands - so that no liquids get into the device.
4. Immediately unplug the device from the outlet and contact the authorized service provided by ACTIVESHOP Ltd. in the following cases:
(a) liquid has entered the device, (b) the device emits a strange odor, smoke or makes strange sounds,
c) the power cord has been damaged, d) the device has been overturned or its housing has been damaged.
5. Do not lay any objects on the cables. Do not install the device where someone may step on the power cord.
6. For safety purposes, unplug the power cord from the outlet each time you finish working with the device.
7. Do not insert anything into the opening of the device. If a foreign object gets into the hole, remove the cord from the outlet and contact the distributor or manufacturer.
8. Do not place the device on an unstable cart, shelf or vehicle. If dropped, the device may be damaged.
9. In order to guarantee the established useful life of the device, it is recommended to keep an interval of one minute before pressing the power button again (between switching on and off and vice versa).
10. The power supply must comply with the specifications on the nameplate. Otherwise, there is a risk of incorrect operation of the device its damage and even burning.

CAUTION:
1. In case of damage of power cord or other malfunctions, contact an authorized authorized service center - this will avoid danger.
2. This equipment may be used by children at least 8 years of age and by persons of diminished physical and mental capabilities and persons with inexperience and lack of familiarity with the equipment, if supervision or instruction on how to use the equipment in a safe manner is provided so that the associated risks are understood.
3. The equipment is not intended for play by children. Do not allow children to play with the equipment.
4. Do not leave the appliance unattended when children or persons without sufficient knowledge of the use of the appliance are in the vicinity.
5. This electrical appliance is not a toy. Improper use or contact with the electrical appliance may pose a health risk or lead to death, so use and store the appliance out of the reach of children.



DISPOSAL OF THE DEVICE

Dispose of used electrical appliances, fixtures and packaging to raw material reprocessing centers in accordance with environmental protection principles. Electrical appliances should not be disposed of in household waste containers. Follow the rules for discarding this type of equipment. In order to protect the environment in accordance with Directive 2012/19/EC on waste electrical and electronic equipment, waste electrical equipment should be collected separately and then sent to collection points for waste electronic and electrical equipment.

At the end of their useful life, as well as old devices contain full-value recyclable components, so they should be handed over for recycling. Therefore, they should be handed over to appropriate collection points, as well as they can also be handed over to ACTIVESHOP Ltd.

STORAGE AND TRANSPORT

The device should be transported at a temperature in the range of (-) 20 °C to (+) 50 °C only in its original packaging. Store the device in a well-ventilated area with a relative humidity of no more than 75%. Operating temperature from (+) 10 °C to (+) 40 °C. During storage and transportation processes, the device must not be thrown or dropped, exposed to mechanical shocks or atmospheric agents.