ACTIVESHOP®

Instructions for use

Giovanni Mini F-17 Vapozone



Importer:
ACTIVESHOP SP. Z O.O.
ul. Graniczna 8b, building DC2A 54-610 Wrocław, Poland
www.activeshop.com.pl
Rev. A/04/2025

Scan for different languages

Giovanni mini F-17 vaporizer is used for vaporization of the face, neck, shoulders and cleavage, as well as other parts of the body.
other parts of the body. Its primary function is to moisturize the skin. Warm water and steam, thanks to their ability to soften dead skin cells, help in the skin cleansing procedure. This device has many possibilities possibilities, in addition, it performs a professional aromatherapy treatment.

There is a distinct smell when the ozone is emitted by the wapozone. The water lord seems more dense and the mist cloud changes. Ozone has antibacterial and disinfectant effects and accelerates the healing of micro injuries. Besides, it stimulates circulation, revitalizes, stimulates all skin functions, especially its immune system.

The device is characterized by its small size and mobility, so you can take it literally anywhere. The vapozone weighs only 1.3kg, which is an additional advantage. Giovanni mini F-17 vapozone is also suitable for home use. The model is functional and easy to use. Steam and active ozone make it possible to perform additional attractive treatments.



DEVICE FUNCTIONS:
1. Softens the skin
2. Expands pores
3. Facilitates skin cleansing
4. Improves blood circulation
5. Improves massage results
6. Has a bactericidal and oxygenating effect

TECHNICAL DATA:
1. Voltage: 230V
2. Frequency: 50/60Hz
3. Power: 450W
4. Weight: 1.3kg
5. Base: 18cm
6. Height: 27cm
7. Nozzle length: 22cm


NOTE!!!
If discomfort is felt during use, stop the treatment immediately

INSTRUCTIONS FOR USING THE DEVICE:
1. Place the device on a stable surface, the device should be placed on a stable and level surface
2. Pour water into the device tank (minimum and maximum levels are described on the tank)
3. Connect the device to the power supply
4. Turn on the device using the "on/off" button

NOTE!!!
If the water level in the tank is too low, the device will automatically turn off. Refill the water in the tank to the designated level. Then the device will turn on after 5 minutes.

RECOMMENDATIONS:
1. It is forbidden to position the device nozzle close to the face, body or treatment area
2. Do not turn on the wapozon without water (make sure the water level is adequate before turning it on)
3. Before adding water to the tank, make sure the device is unplugged
4. Always unplug the Vapozon from the power supply after finishing work
5. The device is not a toy. Keep an eye on children so that they do not play with the device
6. It is forbidden to tilt or overturn the device when the device is running.
7. Do not use the device if there is no water in it
8. Clean the water container regularly
9. Disconnect the appliance from the power supply before removing the water container
10. The safety of the product is guaranteed only if it is used correctly and exactly according to the guidelines in this manual
11. If the power cord is damaged, it must be replaced by an authorized service center

CAUTION!!!
When using an electrical appliance, especially in the presence of children, basic precautions.



1. The device must not be used and stored in Bathroom or other wet areas
2. The device should not be exposed to sunlight, there should be no other devices with high temperatures near the device
3. Pull the plug out of the outlet and contact the service center in the The following situations:
    A. The device has been in contact with water
    B. The device emits a strange smell, smoke or noise
    C. The cable has become damaged
    D. The device has fallen or become damaged
4. Do not put anything on the cable, do not place the device in a place where someone can step on the cable
5. For safety reasons, remove the cable from the socket even when the device is not in use

CAUTION!!!
If the wapozon squeaks when you use it for the first time, clean the water tank and pour fresh, clean water

CAUTION!
Do not pour essential oils or any other liquid other than water into the water tank. This may lead to damage to the device or physical injury.

CAUTION!!!
Do not touch the water tank when the device is turned on.

SAFETY MEASURES
1. The device is a professional equipment for use in beauty parlors. Operation of the device only by qualified cosmetic personnel avoids undesirable consequences during treatment.
2. Do not disassemble the device or attempt to use it for purposes other than those indicated in this manual. All servicing and repairs must be performed only by an authorized service technician (ACTIVESHOP Ltd. company).
3. Do not install or operate the device near liquids, wet places or with wet hands - so that no liquids get into the device.
4. Immediately unplug the device from the outlet and contact the authorized service provided by ACTIVESHOP Ltd. in the following cases:
    A. liquid has entered the device,
    B. the device emits a strange odor, smoke or makes strange sounds,
    C. the power cord has been damaged,
    D. The device has been knocked over or its housing has been damaged.

5. Do not put any objects on the cables. Do not install the device where someone may step on the power cord.
6. For safety purposes, unplug the power cord from the outlet each time you finish working with the device.
7. Do not insert anything into the opening of the device. If a foreign object gets into the hole, remove the cord from the outlet and contact the distributor or manufacturer.
8. Do not place the device on an unstable cart, shelf or vehicle. If dropped, the device may be damaged.
9. In order to guarantee the established useful life of the device, it is recommended to maintain an interval of one minute before pressing the power button again (between switching on and off and vice versa).
10. The power supply must comply with the specifications on the nameplate. Otherwise, there is a risk of incorrect operation of the device its damage and even burning.

CAUTION:
1. In case of damage to the power cord or other malfunctions, contact an authorized service center, this will avoid danger.
2. This device can be used by children at least 8 years old and by people with reduced physical capabilities, mental capabilities and a person with inexperience and lack of familiarity with the equipment, if supervision or instruction on the use of the equipment in a safe manner is provided so that the associated risks are understood.
3. The equipment is not intended for play by children. Do not allow children to play with the equipment.
4. Do not leave the appliance unattended when children or persons without sufficient knowledge of the use of the appliance are in the vicinity.
5. This electrical appliance is not a toy. Improper use of or contact with an electrical appliance may pose a health risk or lead to death, so use and store the appliance out of the reach of reach of children.

DISPOSAL OF THE DEVICE



Dispose of used electrical appliances, fixtures and packaging to raw material reprocessing centers in accordance with environmental protection principles. Electrical appliances should not be disposed of in household waste containers. Follow the rules for discarding this type of equipment. In order to protect the environment in accordance with Directive 2012/19/EC on waste electrical and electronic equipment, waste electrical equipment should be collected separately and then handed over to collection centers for waste electronic and electrical equipment electronic and electrical equipment.

At the end of their useful life, as well as old appliances contain full-value recyclable components, so they should be handed over for reprocessing. Therefore, they should be handed over to appropriate collection points, as well as they can also be handed over to ACTIVESHOP Ltd.

STORAGE AND TRANSPORT

The device should be transported at a temperature in the range of (-)20°C to (+)40°C only in its original packaging. Store the device in a well-ventilated room and a relative humidity of no more than 90%. Operating temperature from (+)10°C to (+)40°C. During the storage and transportation processes, the device must not be thrown or dropped, exposed to mechanical shocks or atmospheric agents.