ACTIVESHOP®

USER MANUAL

Wapozon Giovanni with D-21 Magnifying Lamp



Importer:
ACTIVESHOP SP. Z O.O.
8b Graniczna St., Bldg. DC2A
54-610 Wrocław, Poland
www.activeshop.com.pl
Rev. A/03/2026

Scan for different languages

Thank you for choosing our product.

Please read the user manual before first use and keep it for future reference.


The Giovanni D-21 multifunctional steam **facializer with a magnifying lamp** is a highly effective device that is perfect for any beauty salon. It generates steam that stimulates the skin to cleanse itself and prepares it for further cosmetic treatments. The magnifying lamp allows you to view the skin at high magnification, while providing excellent lighting for the work area.

Technical Specifications	
Voltage	220–240 V, 50 Hz
Power	750W
Lamp brightness	1000–1600 Lx
Lamp power	9.5W
Magnification	5x

Device application





- Disinfects the skin
- Cleanses and opens pores
- Facilitates the removal of blackheads and dead skin cells by allowing steam to penetrate deep into the skin
- Facilitates the elimination of toxins
- Softens, moisturizes, and refreshes the skin
- Stimulates blood circulation
- Significantly improves massage results


Device description



1. On/off switch and timer
2. Opening/filling port
3. Gooseneck tube
4. Light switch
5. Magnifying lens
6. Nozzle emitting hot steam
7. Spray tube
8. Main body
9. Telescopic stand (upper pole; 2-in-1)
10. Telescopic stand (lower pole)
11. Base
12. Casters
13. Cover
14. Water container

Assembly

A:	B:	C:	D:	E:
1 piece	1 piece	1 piece	1 piece	1 piece
				
F:	G:	H:	I:	J:
2 pieces	4 pieces	1 piece	1 piece	4 pieces
				



Step 1 **Step 2** **Step 3** **Step 4**

Step 5 **Step 6** **Step 7** **Step 8**


1. Take two crossbars (F) and press 4 wheels (G) into the holes at the ends of the crossbars. Attach the end caps (J).
2. Cross the beams so that the notches in the center interlock. Place the connecting cover (E) over the center of the crossed beams.
3. Insert the lower stand tube (D) into the hole in component E. Secure the stand from the bottom of the base using a large screw with a washer (H). Tighten firmly to ensure the structure is stable.

4. Insert the upper post with the handle (C) into the lower post (D).
5. Place the main body with the water tank (A) on top of the upper post.
6. Insert the steam nozzle (B) into the side opening in the body (A). Make sure it is fully inserted.
7. Insert the lower end of the magnifying lamp (I) into the designated opening on the tube bracket (C).


The height of the device can be adjusted between 78 and 95 cm, allowing you to position the equipment at the appropriate level to ensure maximum comfort for both the practitioner and the client.
The LED magnifying lamp and the vapozone nozzle can be rotated, which increases the range and scope of the treatment.

Instructions for Use


1. Place the device on a stable and flat surface.
2. Make sure the water tank is securely fastened and positioned at a right angle (90°).
   Check that the hot water seal is tightly secured.



3. Pour clean water through the top filling opening. Top up the water until it reaches the MAX level in the container.




4. Turn the operating time dial to set the desired treatment time (between 0 and 30 minutes).




5. Turn on the device by pressing the on/off button.


   The Wapozon will begin heating the water, and the UV indicator light will turn on. Steam will begin emerge from the nozzle approximately 5 minutes after the water boils. This time may vary depending on the amount and temperature of the water added.



6. The UV light can be activated separately. Press and hold the on/off button for 5 seconds to turn the UV function on or off.



7. When steam begins to emerge from the nozzle, bring the steamer arm close to the client's face.




Note
The ideal distance between the nozzle and the face is about 20 cm. Do not bring the device too close to the skin to avoid burns

If the device is not used for an extended period, pour out the water and dry the container.

Aromatherapy function

- Place a piece of cotton wool into the aromatherapy tube (located at the nozzle outlet).
- Soak the cotton ball with a few drops of essential oil.
- The scent will be released along with the steam.



Temperature Control System

The Wapozon is equipped with a system that protects it from overheating. If the tank runs out of water, the device will automatically shut off, and the steam and UV indicator lights will begin to flash.

1. Add clean water to the tank
2. Wait a moment for the device to cool down
3. When the lights stop flashing and turn off completely, press the on/off button. The device will return to normal operation.

Warning

- Do not expose unprotected eyes to direct LED light, as this may cause discomfort or damage to your eyesight.
- Do not touch the hot water tank.
- Do not touch the water tank while the device is turned on.
- After the treatment is finished, pour out the water and dry the tank.

Warning

- Do not bring the device too close to the client's face or body. This poses a risk of serious skin burns.
- Do not tilt the device while it is in operation.
- Do not use the device if there is no water in it.
- Do not pour essential oils or any liquids other than water into the water tank. This may cause damage to the device or physical injury.

Cleaning and Maintenance

To keep the chair in good working order, ensure its long service life, and maintain proper operation of the device, we recommend regular maintenance and adherence to the following cleaning guidelines.

- Before performing any work, always turn off the device and unplug it from the outlet.
- Wipe the plastic surfaces with a soft, dry, or slightly damp cloth.
- Do not use a rough cloth to clean the lens. This can scratch it and reduce its clarity.
- The water tank should be cleaned regularly.

Recommendations

1. Make sure you have placed the device on a flat, stable surface to reduce the risk of it falling and becoming damaged.
2. Never leave the device plugged in and unattended.
3. Use the device as intended, as described in the manual.
4. Never use this device if the cord or plug is damaged.

5. Do not use the device if it is not working properly or if it has been dropped, damaged, or has come into contact with water.
6. Do not pull directly on the cord to remove the plug from the outlet.
7. This product is for indoor use only. Do not expose it to direct weather conditions.
8. Clean the device periodically to prevent dirt buildup. It is best to clean the device with a damp cloth.
9. Do not wrap the power cord around the device.

Device Dimensions



Safety precautions

1. This device is professional equipment intended for use in beauty salons. To avoid adverse effects during treatment, the device must be operated exclusively by qualified beauty professionals.
2. Do not disassemble the device or attempt to use it for purposes other than those specified in this user manual. All maintenance and repairs must be performed exclusively by an authorized service technician (ACTIVESHOP Sp. z o.o.).
3. Do not install or operate the device near liquids, in wet areas, or with wet hands. Ensure that no liquids enter the device.

4. Immediately unplug the device and contact the authorized service provider, ACTIVESHOP Sp. z o.o., in the following cases: a) liquid has entered the device,
   b) the device emits a strange odor, smoke, or unusual noises, c) the power cord is damaged, d) the device has been knocked over or its housing is damaged.
5. Do not place any objects on the cables. Do not install the device in locations where someone might step on the power cord.
6. For safety reasons, unplug the power cord from the outlet after each use of the device.
7. Do not place foreign objects inside the device. If a foreign object gets inside, unplug the power cord from the outlet and contact the distributor or manufacturer.
8. Do not place the device on an unstable cart, shelf, or vehicle. If it falls, the device may be damaged.
9. To ensure the device's specified service life, it is recommended to wait one minute before pressing the power button again (between turning it on and off
   and vice versa).
10. The power supply must comply with the specifications listed on the nameplate. Otherwise, there is a risk of the device malfunctioning, being damaged, or even catching fire.

CAUTION

1. In the event of damage to the power cord or other malfunctions, contact an authorized service center— this will help prevent hazards.
2. This device may be used by children aged 8 years and older, by persons
   by individuals with reduced physical or mental capabilities, as well as by those unfamiliar with the operation of this equipment, provided they are given appropriate supervision or instruction on how to use it safely and understand the associated risks.
3. Do not leave the device unattended when children or persons without sufficient knowledge of how to use the device are in the vicinity.
4. The device is not intended for use by children. Do not allow children to play with the device.
5. This electrical device is not a toy. Improper use of or contact with the
   may pose a risk of injury or death; therefore, the device must be used and stored out of the reach of children.

Disposal of the device



To protect the environment, in accordance with Directive 2012/19/EU on waste electrical and electronic equipment, used electrical equipment must be collected separately and taken to collection points for waste electrical and electronic equipment. Follow the guidelines for disposing of this
type of equipment and do not dispose of it in household waste bins.
At the end of their useful life, these devices still contain valuable components suitable for recycling; therefore, they should be sent for recycling to appropriate collection points or to ACTIVESHOP Sp. z o.o.

Storage and Transport

The device should be transported at temperatures ranging from (–)20°C to (+)40°C exclusively
in its original packaging. It should be stored in a well-ventilated room with relative humidity not exceeding 90%. Operating temperature range: (+)10°C to (+)40°C. During processes
During storage and transport, do not throw or drop the device, or expose it to mechanical shocks or weather conditions.